



CLEANING:

To keep your AZEK Deck looking its best:

- Wash deck periodically to remove grease, dirt and debris
- AZEK Deck can be cleaned using liquid soap such as dish, car wash or specially formulated all purpose deck cleaners and rinsed with a garden hose.
- For rust stains, use a household cleaner with phosphoric acid as the active ingredient (generally toilet bowl cleaners work well). Rinse with garden hose.
- Avoid using cleaners containing abrasives which can dull the surface of the deck board. It is always best to test the cleaner on an inconspicuous or scrap piece of the deck to make sure the cleaner/product does not harm the deck surface.
- AZEK Deck can be cleaned with a power washer using the FAN setting. PSI should not exceed 1400, this said, always, before spraying the deck, test the pressure on an inconspicuous or scrap piece of the deck to make sure the pressure setting does not harm the deck surface.
- Avoid the use of rubber-backed mats.

ICE REMOVAL:

For Ice Removal:

- Rock Salt or calcium chloride can be used without damage to the deck surface
- Both products may leave a white residue, which can be cleaned using the above guidelines

End-2-2008